



#8 and #4 = Judder spring & seat.

#5 = Larger inside diameter friction plate.

INSTALLATION INSTRUCTIONS HONDA TRX700XX

This kit includes 1 extra full size friction plate. This gives you the option to remove the judder spring seat, judder spring and the larger I.D. friction plate and replace them with a full size friction. You can also choose to stay with the O.E.M combination and retain the judder spring seat, judder spring and larger I.D. friction plate. No matter which combination you choose you will only use 8 friction plates and 7 steel plates total. The O.E.M. combination would be 7 full size friction plates, 1 larger I.D. friction plate the judder spring seat and judder spring. The heavier duty option would be 8 full size friction plates and 7 steel plates.

When installing a new clutch ALWAYS set your clutch adjustments to the OEM specifications.